INSTRUCTIONS – ROUTINE REPAIR PERMIT

Kentucky recognizes "Routine Repairs" as defined by the NBIC. All routine repairs must be done by an "R" Stamp holder.

A Kentucky Repair Permit <u>must be obtained</u> that identifies the routine repairs to be performed. The repair permit must be returned to the state boiler office signed by the AI, whenever the AI visits the site and signs off the repair package R-1 form. The AI is not required to make an inspection visit for each routine repair, but only after the repairs are completed. Follow the NBIC Part III, 3.3.2